## **Quick Reference**

These symbols are used in Operating Controls section:

SYMBOL	COMPONENT	SEE PAGE
N	choke lever	16
0	ON — ignition switch	17
OFF	OFF — ignition switch	17
(3)	START button	18
×	engine stop button	18