Switch Output

When the audio system is turned on, you can switch its output between Speaker and Headset. (Headset is optional equipment.)

• Pushing the AUDIO button switches the output.