

Auxiliary Function

Auxiliary (AUX) Input


Use this function to listen to other audio:

Connect the input jack connector to listen to other audios.

Connect the iPod®/USB flash drive to the USB cable to operate and listen to it (see [page 95](#)).

- To turn the function on — push the AUX button once. (AUX appears on the display.)
push the AUX button twice when connecting a USB device with USB cable (see [page 101](#)). (iPod® or USB appears on the display.)
- To turn the function off — push the AM, FM or WB button.

The following functions operate the same as they do with the AM/FM radio: Switch output, Tone control, Fader control, SRS, AVC, BEEP, Muting.



The display changes as follows each time the AUX button is pushed.

