Audio Systems

## System Control

To turn the audio system on — push the AUDIO button.

AUDIO button

To turn the audio system off — push and hold the AUDIO button.