


INFO 3 Display




INFO 3 display contains the following:

- Coolant temperature gauge (🌡️) [➡ P. 41](#)
- Travel trunk **GL1800/D/DA** & Saddlebags open indicator [➡ P. 41](#)
- Side stand indicator [➡ P. 42](#)
- Handle grip heater indicator (🔥) [➡ P. 42](#)

- **GL1800/D/DA**
Rider seat heater indicator (🔥/1) [➡ P. 42](#)
- **GL1800/D/DA**
Passenger seat heater indicator (🔥/2) [➡ P. 43](#)
- **GL1800/D/DA**
Suspension preload indicator (🚲) [➡ P. 43](#)

Coolant Temperature Gauge (🌡️)

When the coolant is over the specified temperature, the 6th (H) segment flashes and the high coolant temperature indicator comes on.




If the 6th (H) segment flashes while riding: [➡ P. 178](#)

If the all segments flashes: [➡ P. 184](#)

Travel Trunk **GL1800/D/DA** & Saddlebags Open Indicator

The segment(s) of open component(s) flashes with the "OPEN" indicator when your vehicle's travel trunk and/or saddlebags are open.

Travel trunk open **GL1800/D/DA**



Saddlebag open

