


Instruments (Continued)

Side Stand Indicator

The side stand segment flashes with the "STAND" when the side stand is put down. It goes off when the side stand is raised.

Side stand segment




"STAND" indicator

Handle Grip Heater Indicator

Comes on when the handle grip heater is on and indicates the selected heater level. The handle grip heater has 5 levels.

Handle grip heater indicator



When the handle grip heater indicator flashes, go to your dealer for service.

To operate the handle grip heater:

➡ P. 133

If the handle grip heater indicator blinks:


➡ P. 183

Rider Seat Heater Indicator

GL1800/D/DA

Comes on when the rider seat heater is on and indicates the selected heater level. The rider seat heater has 5 levels.

Rider seat heater indicator



When the rider seat heater indicator flashes, go to your dealer for service.

To operate the rider seat heater:

➡ P. 134

If the rider seat heater indicator blinks:

➡ P. 184