


Shelter Case Except GL1800DA

The shelter case is for lightweight items. Cargo should not exceed:
6.6 lb (3.0 kg)

- Press the shelter case opener, the shelter case lid opens.
- To close the shelter case, push the lid until it is firmly closed.
- ▶ Do not store valuables in the shelter case.
 - ▶ Make sure the shelter case is closed before riding.
 - ▶ Be careful not to flood this area when washing your vehicle.

Shelter case opener



Shelter case lid


Helmet Holder

The helmet holder is located on the left grab rail.

▶ Use the helmet holder only when parked.

- 1 Open the left saddlebag P.128 and take up the helmet holder hanger. P.132
- 2 Pull the helmet holder release lever backward to unlock the helmet holder pin.

Helmet holder pin Helmet holder release lever



- 3 Insert the helmet holder hanger into the helmet D-ring.

