

## If a Fuse Blows

---

If you do not have a spare fuse and you cannot drive the Honda MUV without fixing the problem, take a fuse of the same rating or a lower rating from one of the other circuits that you can do without temporarily.

If you replace a blown fuse with a spare fuse that has a lower rating, replace the fuse with the correct rating as soon as you can. Also remember to replace any spare fuses that were installed.

If the replacement fuse of the same rating burns out in a short time, there is probably a serious electrical problem on your Honda MUV. Leave the blown fuse in that circuit and have your Honda MUV checked by your dealer.