

## Instruments *(Continued)*

### **Reserve tripmeter (only when reserve fuel mode)**

Distance ridden since the 1st (E) segment of the fuel gauge and "RES" start flashing.

The "RES" will flash faster when the fuel decreases further.

When the fuel gauge is near the 1st (E) segment or flashes, fill fuel promptly.

When "----." is displayed, go to your dealer for service.

### **Reserve fuel consumption (only when reserve fuel mode)**

Fuel consumption since the 1st (E) segment of the fuel gauge and "RES" start flashing.

The "RES" will flash faster when the fuel decreases further.

When the fuel gauge is near the 1st (E) segment or flashes, fill fuel promptly.

When "---." is displayed, go to your dealer for service.

