


Indicators & Displays

Drive Mode Indicator (SXS1000M3P/M3D/M5P/M5D)

The drive mode indicator shows the selected drive mode by the drive mode select lever (page 44, 106).

4WD differential lock indicator

This indicator comes on when the differential gears are engaged.



drive mode select lever position	Turf	2WD	4WD	4WD Diff Lock
drive mode indicator				
4WD differential lock indicator	No indicator light.			