

Sub-Transmission Oil

Oil Recommendation

The recommended sub-transmission oil is the same as the engine oil (page 149).

Checking & Adding Sub-Transmission Oil

Refer to *Safety Precautions* on page 123.

Check the sub-transmission oil level each day before operating your Honda SXS and add, if needed.

Before driving your SXS, check the sub-transmission oil level.

1. Park your Honda SXS on a firm, level surface.
2. Remove the front seat (page 139).
3. Remove the clips (page 143).
4. Fold open the rubber dust cover.
5. Remove the oil fill cap/dipstick from the transmission cover and wipe it clean.
6. Insert the dipstick without screwing it in, then remove the oil fill cap/dipstick and check the oil level. The oil level should be between the upper level mark and the lower level mark on the oil fill cap/dipstick.

(cont'd)