

# Storing Your Honda

---

## Removal from Storage

Refer to *Safety Precautions* on page 123.

1. Uncover and clean your Honda SXS.
2. If your Honda SXS has been stored for more than four months — change the engine oil (page 153).
3. If your Honda SXS has been stored for more than two months — ask your dealer to drain and replace the fuel.
4. Charge the battery (page 216) as required. Install the battery.
5. Perform a pre-ride inspection (page 90), then test-ride your Honda SXS at low speeds.