

Index

| | |
|---------------------------|-----|
| fuel, | |
| fill cap | 113 |
| gauge | 25 |
| oxygenated | 242 |
| recommendation | 123 |
| refueling | 124 |
| reserve fuel supply | 124 |
| tank capacity | 124 |
| fuses | 220 |

G

| | |
|------------------------|----------|
| gap, spark plug | 155, 233 |
| gasohol | 242 |
| gasoline | 123 |
| gear shifting | 79 |
| gearshift switch | 41 |
| guards | 179 |

H

| | |
|--|-------------|
| headlight dimmer switch | 37 |
| headlight switch | 37 |
| high coolant temperature indicator | 14, 17, 218 |
| hills, | |
| crossing or turning on slopes | 97 |
| riding down hills | 96 |
| riding up hills | 92 |
| stopping on hills | 94 |
| Honda service manual | 246 |
| Honda, | |
| contacting | 249 |
| dealer | 250 |
| Rider's Club | 251 |
| hourmeter | 31 |