

# Maintenance

Please read “Importance of Maintenance” and “Maintenance Fundamentals” carefully before attempting any maintenance. Refer to “Specifications” for service data.

An optional larger tool kit may be available. Check with your Honda dealer’s parts department.

<b>Importance of Maintenance</b> .....	P. 32	<b>Final Drive Oil</b> .....	P. 65
<b>Maintenance Schedule</b> .....	P. 34	<b>Brakes</b> .....	P. 67
<b>Maintenance Fundamentals</b> .....	P. 37	<b>Side Stand</b> .....	P. 70
<b>Removing &amp; Installing Body Components</b> ...	P. 49	<b>Clutch</b> .....	P. 71
Seat .....	P. 49	<b>Throttle</b> .....	P. 74
Side Covers .....	P. 51	<b>Crankcase Breather</b> .....	P. 75
Clip .....	P. 52	<b>Other Adjustments</b> .....	P. 76
Battery .....	P. 53	Headlight Aim .....	P. 76
<b>Spark Plug</b> .....	P. 54	Rear Suspension .....	P. 77
<b>Engine Oil</b> .....	P. 58		
<b>Air Cleaner</b> .....	P. 62		
<b>Coolant</b> .....	P. 63		