




16. WIRING DIAGRAM



- B BLACK
- Y YELLOW
- Bu BLUE
- G GREEN
- R RED
- W WHITE
- BROWN
- O ORANGE
- Ls LIGHT BLUE
- Lg LIGHT GREEN
- P PINK
- Gr GRAY

ENGINE STOP SWITCH-STARTER SWITCH

| | | | |
|-----|-----|------|------|
| IG | E | ST | N |
| OFF | ON | FREE | PUSH |
| RUN | OFF | ON | |

HORN SWITCH

| | |
|------|------|
| HO | E |
| FREE | PUSH |
| | |

TURN SIGNAL SWITCH

| | | |
|----|----|---|
| R | WR | L |
| ON | N | L |
| | | |

DIMMER SWITCH

| | | |
|------|------|---|
| CI | Lg | H |
| FREE | PUSH | |
| | | |

SWITCH CONTINUITY

| | | | |
|-----|----|-----|----|
| IG | E | BAT | HO |
| OFF | ON | | |
| | | | |

0030Z-GB5-6700