

MODEL CD 90, (CT 90)



Fig. 5.41 Torquing points on left side



Fig. 5.42 Torquing points on right side

- | | |
|--|--|
| ① Handle installation nuts
(90~110 kg·cm; 6.5~7.95 lbs·ft) | ⑧ Rear cushion upper and lower nuts
(300~400 kg·cm; 21.7~25.3 lbs·ft) |
| ② Steering stem nut
(800 kg·cm; 56 lbs·ft) | ⑨ Rear wheel spokes
(6~25 kg·cm; 0.55~1.8 lbs·ft) |
| ③ Front cushion upper bolts
(300~400 kg·cm; 21.7~25.3 lbs·ft) | ⑩ Front brake torque link lock nuts
(300~400 kg·cm; 21.7~25.3 lbs·ft) |
| ④ Front arm pivot bolts
(300~400 kg·cm; 21.7~25.3 lbs·ft) | ⑪ Engine hanger nuts
(200~250 kg·cm; 14.5~18 lbs·ft) |
| ⑤ Front and rear axle nut
(300~400 kg·cm; 21.7~25.3 lbs·ft) | ⑫ Rear fork pivot nut
(200~250 kg·cm; 14.5~18 lbs·ft) |
| ⑥ 8×46 hex bolt
(300~400 kg·cm; 21.7~25.3 lbs·ft) | ⑬ Rear brake torque link nut
(200~250 kg·cm; 14.5~18 lbs·ft) |
| ⑦ Front wheel spokes
(4~21 kg·cm; 0.3~1.5 lbs·ft) | |