

7. MAINTENANCE SCHEDULE

Service Required	Months or Miles, whichever occurs first					
		First	Second	Third	Thereafter Repeat Every	
	Month	—	6	12	6 12	
	Mile	200	3,000	6,000	3,000 6,000	
	Km	300	5,000	10,000	5,000 10,000	
Engine Oil—change	<input type="radio"/>	Every 1,000 Miles (1,600 Km)				
Oil Filter—clean	<input type="radio"/>		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
Spark Plugs—clean and adjust or replace			<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
Cam Chain—adjust	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		
Contact Breaker Points—check or service		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		
Ignition Timing—check or adjust	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		
Valve Tappet Clearance—check or adjust	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		
Air Cleaner—clean and replace		<input type="radio"/>	<input type="radio"/>		<input type="radio"/>	
Throttle Operation—check		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		
Carburetor—check or adjust		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		
Fuel Valve Strainer—clean		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		
Fuel Tank and Fuel Lines—check		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		
Clutch—check or adjust	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		
Drive Chain and Sprockets—adjust and lubricate or replace	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		
Front and Rear Brake—adjust	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		
Front and Rear Brake Shoes—check or replace			<input type="radio"/>		<input type="radio"/>	
Front and Rear Brake Links—check		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		
Wheel Rims and Spokes—check	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		
Tires—check or replace		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		
Front Fork Oil—check for leakage and change		<input type="radio"/>			<input type="radio"/>	
Steering Head Bearings—check or adjust			<input type="radio"/>		<input type="radio"/>	
Steering Handle Lock—check for operation			<input type="radio"/>		<input type="radio"/>	
Side Stand Spring—check		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		
Battery Electrolyte Level—check and replenish if necessary	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		
Lights, Horn, Speedometer—check for operation or adjust		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		