

SUPPLEMENT

● SERVICE TOOL.....	75	III ENGINE, CHASSIS AND	
I MAINTENANCE OPERATIONS	77	ELECTRICAL	85
1. Tappet clearance adjustment	77	● ENGINE	85
2. Carbretor adjustment	77	1. CLUTCH.....	85
3. Breaker point and ignition	77	2. TRANSMISSION.....	86
4. Oil filter cleaming.....	77	● CHASSIS.....	87
5. Engine oil change	78	1. Brake arm	87
6. Cam chain adjustment	78	2. Handle Bar	87
7. Fuel system inspection.....	78	3. Cables and read wires	87
8. Air cleaner maintenance	78	4. Front suspension	88
9. Clutch wire adjustment	79	A. Disassmbly notes	88
10. Drive chain adjustment	79	B. Inspection	89
11. Front Brake adjustment	80	C. Assembly	89
12. Rear Breke adjustment	80	● ELECTRICAL SYSTEM	90
13. Brake pedal height adjustment	81	1. A.C Generator.....	91
14. Gear change pedal height adjustment	81	A. Removal	92
15. Front suspension spring adjustment	81	B. Stator Inspection	92
16. Front fork oil change	81	● INSPECTION OF ELECTRICAL	
17. Cylinder compression lnspection	82	ACCESSORIES	92
II ENGINE	83	TABLE OF OPTIONAL PARTS	93
1. IN-mortorcycle	83	SPECIFICATIONS	94
2. Engine removal and installation.....	83	MAINTENANCE SCHEDULE.....	95
A. Engine Romoval	83	TL125 WIRING DIAGRAM.....	96
B. Engine Installation Notes	84		