


SYSTEM DIAGRAM



- (1) Engine stop relay
- (2) Main fuse B (30A)
- (3) Engine stop switch
- (4) Sub-fuse (10A)
- (5) Ignition switch
- (6) Main fuse A (30A)
- (7) Bank angle sensor
- (8) Sub-fuse (10A)
- (9) Battery
- (10) Immobilizer receiver
- (11) Pressure regulator
- (12) IAT sensor
- (13) Spark plug
- (14) PAIR solenoid valve
- (15) TP sensor
- (16) MAP sensor
- (17) Injector

- (18) Cam pulse generator
- (19) PAIR check valve
- (20) ECT sensor
- (21) Knock sensor
- (22) Ignition pulse generator
- (23) O<sub>2</sub> sensor
- (24) Water temperature meter
- (25) Fuel cut relay
- (26) Fuel pump
- (27) Vehicle speed sensor
- (28) Neutral switch
- (29) Clutch switch
- (30) Side stand switch
- (31) Malfunction indicator
- (32) Immobilizer indicator
- (33) Service check connector
- (34) Tachometer