





## a. DISASSEMBLY AND ASSEMBLY

### • CARBURETOR TOP AND THROTTLE VALVE




- 3 Remove the cable end from the throttle valve through the groove.



- 14
- Turn in the adjuster all the way.
  - Be certain that the end of the throttle cable outer casing is inserted in the adjuster securely.
  - Tighten the rubber cap securely.
  - After assembling the carburetor, adjust the throttle grip free play. Page 68.

### • THROTTLE VALVE INSTALLATION



- 17
- Align the groove in the valve with the stop screw when installing the throttle valve.