




● REAR WHEEL



● WHEEL BEARING DRIVING

7 INSTALLATION DIRECTION OF SNAP RING



14 NOTE
Drive the bearing squarely.