


3. CYLINDER HEAD, CAMSHAFT, CYLINDER AND PISTONS



(1) Cylinder head cover  
 (2) Sealing washer  
 (3) Right rocker arm shaft

Referring to rocker arm service on page 131

- Fig. 4-12
- |                              |                            |                                 |
|------------------------------|----------------------------|---------------------------------|
| (1) Rocker arm               | (11) Point cover           | (21) Cylinder head gasket       |
| (2) Rocker arm shaft (L)     | (12) Valve cotter          | (22) Cylinder                   |
| (3) Tachometer gear          | (13) Valve spring retainer | (23) Cylinder gasket            |
| (4) Cylinder head cover      | (14) Valve outer spring    | (24) Cam chain tensioner holder |
| (5) Breather cover           | (15) Valve inner spring    | (25) Tensioner slipper          |
| (6) Breather tube            | (16) Valve stem seal       | (26) 22 x 35 x 6 oil seal       |
| (7) Spark advancer           | (17) Valve spring seat     | (27) Camshaft                   |
| (8) Contact breaker assembly | (18) Valve guide           | (28) Cam sprocket               |
| (9) Contact breaker          | (19) Cam chain guide       | (29) Cam chain                  |
| (10) Point cover gasket      | (20) Cylinder head         | (30) Valve                      |