

MAINTENANCE SCHEDULE

Perform the Pre-ride inspection in the Owner's Manual at each scheduled maintenance period.

I: Inspect and Clean, Adjust, Lubricate or Replace if necessary. C: Clean. R: Replace. A: Adjust. L: Lubricate.

The following items require some mechanical knowledge. Certain items (particularly those marked * and **) may require more technical information and tools. Consult their authorized HONDA dealer.

ITEMS	FREQUENCY	WHICHEVER COMES FIRST ↓	⇨ ODOMETER READING (NOTE 1)								REFER TO PAGE
			× 1,000 km	1	6	12	18	24	30	36	
			× 1,000 mi	0.6	4	8	12	16	20	24	
			Months	6	12	18	24	30	36		
* FUEL LINE					I		I		I	3-4	
* THROTTLE OPERATION					I		I		I	3-4	
* CARBURETOR CHOKE					I		I		I	3-5	
AIR CLEANER		NOTE 2				R			R	3-5	
SPARK PLUG					I		R		I	3-5	
* VALVE CLEARANCE							I			3-7	
ENGINE OIL			R		R		R		R	3-12	
ENGINE OIL FILTER			R		R		R		R	3-12	
* CARBURETOR SYNCHRONIZATION					I		I		I	3-14	
* ENGINE IDLE SPEED			I	I	I	I	I	I	I	3-15	
RADIATOR COOLANT		NOTE 3			I		I		R	3-16	
* COOLING SYSTEM					I		I		I	3-16	
* SECONDARY AIR SUPPLY SYSTEM					I		I		I	3-17	
DRIVE CHAIN			EVERY 1,000 km (600 mi) I,L							3-17	
DRIVE CHAIN SLIDER					I		I		I	3-22	
BRAKE FLUID		NOTE 3		I	I	R	I	I	R	3-22	
BRAKE PAD WEAR				I	I	I	I	I	I	3-23	
BRAKE SYSTEM			I		I		I		I	3-23	
* BRAKE LIGHT SWITCH					I		I		I	3-24	
* HEADLIGHT AIM					I		I		I	3-24	
CLUTCH SYSTEM					I		I		I	3-25	
SIDE STAND					I		I		I	3-25	
* SUSPENSION					I		I		I	3-26	
* NUTS, BOLTS, FASTENERS			I		I		I		I	3-27	
** WHEELS/TIRES					I		I		I	3-27	
** STEERING HEAD BEARINGS			I		I		I		I	3-28	

* Should be serviced by an authorized HONDA dealer, unless the owner has proper tools and service data and is mechanically qualified.

** In the interest of safety, we recommend these items be serviced only by an authorized HONDA dealer.

- NOTES:
- At higher odometer reading, repeat at the frequency interval established here.
 - Service more frequently when riding in unusually wet or dusty areas.
 - Replace every 2 years, or at indicated odometer interval, whichever comes first. Replacement requires mechanical skill.