




Loosen the air cleaner connecting tube bands.  
Remove the three air cleaner mounting bolts and the air cleaner case.  
Check the air cleaner case for deterioration and replace if necessary.  
Check the breather tube for restriction.



BOLTS

AIR CLEANER CASE

### INSTALLATION

Install the air cleaner case in the reverse order of removal.

