





HANDLEBARS

Disconnect the clutch switch wires from the switch. Remove the left handlebar switch by removing the two screws.



Disconnect the choke cable from the choke lever.



Remove the clutch master cylinder.

