





Assemble the brake shoes, springs and brake cam as shown and install the assembly onto the brake panel.



Install the anchor pin plate and new cotter pins.



Install the felt seal.  
Install the wear indicator aligning its tab with the slot in the brake cam.

