

FOREWORD

This shop manual describes the maintenance, inspection and adjustment procedures for the HONDA CB750 and CB750F.

The manual is divided into various functional groups to simplify the use. The pages for the respective groups are indexed on this pages for convenience.

Each of the groups are further divided into section 1. Description, 2. Specifications, 3. Diagnosis, 4. Disassembly, 5. Inspection and 6. Reassembly. Photographs and illustrations make the operations easier to understand.

Following are the initial serial numbers of each model at the time of change.

CB750	Frame No. 1000001~
CB750K1	Frame No. 1055004~
CB750K2	Frame No. 2000001~
CB750K3	Frame No. 2200001~
CB750K4	Frame No. 2341915~
CB750K5	Frame No. 2525947~
CB750F	Frame No. 1000002~
CB750F1	Frame No. 2000003~
CB750K6	Frame No. 2540001~
CB750K7 ('77)	Frame No. 2700002~
CB750F ('77)	Frame No. 2100001~
CB750K ('78)	Frame No. 2800001~
CB750F ('78)	Frame No. 3100002~

GROUP INDEX

1. GENERAL INFORMATION. . . 1~15
2. ENGINE REMOVAL AND INSTALLATION. 17~19
3. ENGINE MECHANICAL. . . . 21~55
4. CLUTCH. 57~61
5. TRANSMISSION. 63~70
6. FUEL SYSTEM. 71~82
7. IGNITION SYSTEM 83~92
8. CHARGING SYSTEM. 93~102
9. STARTING SYSTEM 103~108
10. BATTERY. 109~113
11. STEERING AND FRONT SUSPENSION. 115~122
12. REAR SUSPENSION. 123~128
13. WHEELS, TIRES AND FINAL DRIVE 129~139
14. BRAKES 141~149
15. BODY, OIL TANK, AIR CLEANER AND EXHAUST SYSTEM. 151~156
16. BODY ELECTRICAL AND INSTRUMENTS 157~170
17. WIRING DIAGRAM 171~172
18. ENGINE TUNE-UP 173~174
19. PERIODICAL MAINTENANCE. 175~188
20. SUPPLEMENT TO CB750K1~K4. 189~220
21. SUPPLEMENT TO CB750K5. 221~224
22. SUPPLEMENT TO CB750F 225~248
23. SUPPLEMENT TO CB750K6 ('76). 249~252
24. SUPPLEMENT TO CB750K7 ('77). 253~264
25. SUPPLEMENT TO CB750F ('77). 265~273
26. SUPPLEMENT TO CB750K ('78) 275~279
27. SUPPLEMENT TO CB750F ('78) 281~283

