



GENERAL INFORMATION

BATTERY/CHARGING SYSTEM

ITEM	Q'TY	DIA	TRQ	REMARKS
Battery band bolt	1	6	9.0	

LIGHTING SYSTEM

ITEM	Q'TY	DIA	TRQ	REMARKS
Headlight mounting nut	3	6	7.5	
Front side cover screw	4	4	1.0	
Turn signal light mounting nut	4	10	19	
License light screw	2	4	1.0	

OTHERS

ITEM	Q'TY	DIA	TRQ	REMARKS
Throttle cable A adjuster lock nut (handlebar side)	1	7	3.8	
Seat lock assembly mounting bolt	2	6	12	Replace with a new one.
Throttle cable A nut (handlebar side)	1	10	3.0	
Throttle cable B nut (handlebar side)	1	12	3.0	

SPECIAL TOOL LIST

TITLE	TOOL No.	TOOL NAME
Fuel & Engine	07406-0040004	Fuel pressure gauge
	070MJ-K260100	Fuel pressure gauge attachment
	070MF-KVS0300	Fuel pump case remover
	070PZ-ZY30100	SCS connector
	07708-0030200	Locknut wrench, 10 x 12 mm
	07908-KE90000	Tappet adjusting wrench, 3 x 4 mm
	070MG-0010100	Tensioner stopper
	07757-0010000	Valve spring compressor
	07984-MA60001	Valve guide reamer, 5.0 mm
	07942-MA60000	Valve guide driver, 4.8 mm
	07724-0010200	Gear holder
	07GMB-KT70101	Clutch center holder
	07725-0040001	Flywheel holder
	07933-KM10001	Flywheel puller
Frame & Chassis	07746-0050400	Remover head, 15 mm
	07746-0050100	Bearing remover shaft
	07746-0010300	Attachment, 42 x 47 mm
	07746-0040300	Pilot, 15 mm
	07749-0010000	Driver
	070MF-MEN0100	Bearing installer
	07916-3710101	Steering stem socket wrench
	07GMD-KS40100	Ball race remover shaft
	07946-4300101	Steering stem driver
	07746-0050500	Remover head, 17 mm
	07746-0050100	Bearing remover shaft
	07746-0040400	Pilot, 17 mm
	07746-0010900	Attachment, 40 x 42 mm
	07746-0040500	Pilot, 20 mm
07914-SA50001	Snap ring pliers	
Electrical System	07HGJ-0020100	Peak voltage adapter