


EMISSION CONTROL INFORMATION LABELS (U.S.A. only)

An Emission Control Information Label is located on the as shown. The fuel tank must be opened to read it. Refer to page 6-61 fuel tank opening.



VACUUM HOSE ROUTING DIAGRAM LABEL (CALIFORNIA TYPE ONLY)

The Vacuum Hose Routing Diagram Label is on the air cleaner housing cover as shown. The fuel tank must be opened to read it. Refer to page 6-61 for fuel tank opening.

