

## FUEL SYSTEM (Programmed Fuel Injection)

DTC	Function Failure	Causes	Symptoms	Refer to
33-1	E <sup>2</sup> -PROM in ECM malfunction	<ul style="list-style-type: none"><li>Faulty ECM</li></ul>	<ul style="list-style-type: none"><li>Engine operates normally</li><li>Does not hold the self-diagnosis data</li></ul>	6-55
48-1	No.3 Secondary injector circuit malfunction	<ul style="list-style-type: none"><li>Loose or poor contact on No.3 Secondary injector connector</li><li>Open or short circuit in No.3 Secondary injector wire</li><li>Faulty No.3 Secondary injector</li></ul>	<ul style="list-style-type: none"><li>Engine does not start</li></ul>	6-49
49-1	No.4 Secondary injector circuit malfunction	<ul style="list-style-type: none"><li>Loose or poor contact on No.4 Secondary injector connector</li><li>Open or short circuit in No.4 Secondary injector wire</li><li>Faulty No.4 Secondary injector</li></ul>	<ul style="list-style-type: none"><li>Engine does not start</li></ul>	6-49