

22. TROUBLESHOOTING

ENGINE DOES NOT START OR
IS HARD TO START 22-2

ENGINE LACKS POWER 22-3

POOR PERFORMANCE AT LOW
AND IDLE SPEED 22-5

POOR PERFORMANCE AT HIGH SPEED 22-6

POOR HANDLING 22-6