

FRONT MASTER CYLINDER

Removal

* When working on brake fluid ensure no foreign particles enter each part
* In order to drain fluid, cover the hose joint

Drain brake fluid (14.3)
Remove brake hose bolt and remove brake hose
Remove wire connection from front stop light switch.
Remove holder bolt and remove master cylinder

Remove reservoir hose
Remove bolt and take off reservoir from master cylinder

Remove front stop light switch

Remove brake lever

Remove boot

Remove rubber cap and snap ring and take off reservoir hose joint

