# **TROUBLESHOOTING**

## Engine cranks but own't start

- 1. No fuel in tank.
- 2. No fuel to carburetor.
- 3. Engine flooded with fuel.
- 4. No spark at plug (ignition system faulty).
- 5. Air cleaner clogged.
- 6. Intake air leak.
- 7. Improper choke operation.
- 8. Improper throtle operation.

# Hard starting or stalling after starting

- 1. Improper choke operation.
- 2. Ignition malfunction.
- 3. Carburetor faulty.
- 4. Fuel contaminated.
- 5. Intake air leak.
- 6. Idle speed incorrect.

#### Rough idle

- 1. Ignition system faulty.
- 2. Idle speed incorrect.
- 3. Incorrect carburetor synchronization.
- 4. Carburetor faulty.
- 5. Fuel contaminated.

#### Misfiring during acceleration

1. Ignition system faulty.

#### Misfiring during acceleration

- Ignition system faulty.

### **Backfiring**

- 1. Ignition system faulty.
- 2. Carubretor faulty.

## Poor performance (driveability) and poor fuel economy

- 1. Fuel system clogged.
- 2. Ignition system faulty.

#### Lean mixture

- 1. Clogged fuel jets.
- 2. Piston stuck closed.
- 3. Faulty float valve.
- 4. Float level low.
- 5. Fuel cap vent blocked.
- 6. Fuel strainer screen clogged.
- 7. Restricted fuel line.
- 8. Intake air leak.
- 9. Restricted or faulty fuel pump

#### Rich mixture

- 1. Clogged air jets.
- 2. Faulty float valve.
- 3. Float level too high.
- 4. Choke bystarter stuck clogged.
- 5. Dirty air cleaner.