


Remove the radiator mounting bolt.

Remove the radiator while pulling the upper and lower hoses off.

RADIATOR MOUNTING BOLT




DISASSEMBLY

Remove the fan shroud with the fan by removing the four bolts.

FAN

FAN SHROUD



BOLTS

Remove the fan attaching nut and pull the fan off the fan motor.

FAN

NUT

