


DISASSEMBLY

CAUTION:


*Do not leave the instruments upside down or damping fluid will leak onto the inside of the lens.*

Remove the screws attaching the indicator panel and panel.



Remove the screws attaching the fuse holder and fuse holder from the instruments.

Remove the socket bolts attaching the instruments to the bracket.



Remove the meter lower cover screws.

