



FRONT WHEEL/SUSPENSION

Remove the right handlebar switch assembly and disconnect the front brake switch wires.



Remove the brake master cylinder.



Remove the handlebar upper holder and handlebars.

