


FRONT FORKS


REMOVAL

Remove the following parts:

- front wheel.
- brake calipers.
- front fender.



Remove the fork brace.



Loosen the fork upper and lower pinch bolts and remove the front fork tube.

