

BATTERY/CHARGING SYSTEM

VOLTAGE REGULATOR PERFORMANCE TEST

Connect a voltmeter across the battery.
Check regulator performance with the engine running. The regulator must divert current to ground when battery voltage reaches 14.0 ~ 15.0 V.

