

MAINTENANCE SCHEDULE .....	3-2	DRIVE CHAIN .....	3-9
FUEL STRAINER SCREEN .....	3-3	DRIVE CHAIN SLIDER .....	3-11
THROTTLE OPERATION.....	3-3	BRAKE FLUID (XR125LK/LEK) .....	3-12
AIR CLEANER.....	3-4	BRAKE SHOES/PADS WEAR .....	3-12
AIR CLEANER SUB FILTER (XR125LK/LEK) .. 3-4		BRAKE SYSTEM .....	3-13
CRANKCASE BREATHER .....	3-5	BRAKE LIGHT SWITCH .....	3-14
SPARK PLUG.....	3-5	HEADLIGHT AIM .....	3-15
VALVE CLEARANCE.....	3-6	CLUTCH SYSTEM .....	3-15
ENGINE OIL .....	3-7	SIDESTAND .....	3-16
ENGINE OIL STRAINER SCREEN .....	3-7	SUSPENSION .....	3-16
ENGINE OIL CENTRIFUGAL FILTER .....	3-8	NUTS, BOLTS, FASTENERS .....	3-16
ENGINE IDLE SPEED .....	3-8	WHEELS/TIRES .....	3-16
SECONDARY AIR SUPPLY SYSTEM (XR125LK/LEK).....	3-9	STEERING HEAD BEARINGS .....	3-17