



## INLET DUCT CAP AND MUFFLER DIFFUSER PIPE

A muffler diffuser pipe and inlet duct cap installed will reduce the noise level to 86dB(A).

Some state noise level regulations prohibit operation of this vehicle without the inlet duct cap and muffler diffuser pipe installed.

Determine that operation of the vehicle complies with off-road laws and regulation.

### INLET DUCT CAP

Remove the seat.

Insert the duct cap into the air cleaner inlet tube securely.

Install the seat.



### MUFFLER DIFFUSER PIPE

Remove the two screws from the end of the spark arrester. Attach the muffler diffuser pipe into the end of the spark arrester with the two screws and tighten securely.

