




LUBRICATION POINTS

Use general purpose grease when not specified here.
Apply oil or grease to the other sliding surfaces and cables not shown here.



- SPECIAL LUBRICANT**
- SHOCK ABSORBOR UPPER MOUNT BUSHINGS (page 14-18).
 - SUSPENSION LINKAGE PIVOTS (page 14-20).