



## CYLINDER/PISTON

---

### TROUBLESHOOTING

#### **Low or Unstable Compression**

1. Worn cylinder or piston rings.

#### **Excessive Smoke**

1. Worn cylinder, piston, or piston rings
2. Improper installation of piston rings
3. Scored or scratched piston or cylinder wall

#### **Overheating**

1. Excessive carbon build-up on piston crown or combustion chamber

#### **Knocking or Abnormal Noise**

1. Worn piston and cylinder
2. Excessive carbon build-up on piston crown or combustion chamber