


## FUEL SYSTEM

---

### INSTALLATION

Install the air cleaner in the reverse order of removal.



## CRANKCASE BREATHER

Route the crankcase breather tube as shown.

