


6. With the throttle closed, push the starter button (4). Release the starter button as soon as the engine starts.

NOTE:

- * Do not use the electric starter for more than 5 seconds at a time. Release the starter button for approximately 10 seconds before pressing it again.



(4) Starter button

7. Be sure to keep the throttle closed and the parking brake (2) locked while warming up the engine.
8. Allow the engine to warm up before riding (See “RIDING,” page 60).

▲WARNING

- * Do not “BLIP” the throttle (open and close rapidly) as the scooter will move forward suddenly, causing possible loss of control.
- * Do not leave the scooter unattended while the engine is warming up.

