Is Your Motorcycle Ready to Ride?

If you are carrying a passenger or cargo, also check the following:

Load Limits	Make sure you do not exceed the load limits (page 42).
Cargo	Check that all cargo is secure.
Adjustments	Adjust the rear suspension (page 156) according to your load.
Check these items after you get on the motorcycle:	
Throttle	Rotate the throttle to check it moves smoothly without binding.
Brakes	Pull the brake lever and press on the brake pedal to check that they operate normally.
Indicators	Turn the ignition on and check for normal operation of the indicators (page 15).
Gauges	Check the fuel level and other gauges (page 15).

If you haven't ridden the motorcycle in over a week, you should also check other items, such as the oil level and other fluids. See *Periodic Maintenance* (page 119). Periodic maintenance should also be done at least once a month, no matter how often you ride.

Remember, be sure to take care of any problem you find, or have your dealer correct it before you ride.