

## Introduction

This service manual describes the service procedures for the SK50M.

This Model Specific Manual includes every service procedure that is of a specific nature to this particular model. Basic service procedures that are common to other Honda Motorcycles/Motor Scooters/ATVs are covered in the Common Service Manual. This Model Specific Service Manual should be used together with the Common Service Manual in order to provide complete service information on all aspects of this scooter.

Follow the Maintenance Schedule (Section 3) recommendations to ensure that the vehicle is in peak operating condition. Performing the first scheduled maintenance is very important. It compensates for the initial wear that occurs during the break-in period.

Sections 1 and 3 apply to the whole scooter. Section 2 illustrates procedures for removal/installation of components that may be required to perform service described in the following sections.

While Sections 4 through 17 describe parts of the scooter, grouped according to locations.

Find the section you want on this page, then turn to the table of contents on the first page of the section.

Most sections describe the service procedure through system illustration. Refer to the next page for details on how to use this manual.

If you don't know the source of the trouble, go to section 18 TROUBLESHOOTING.

ALL INFORMATION, ILLUSTRATIONS, DIRECTIONS AND SPECIFICATIONS INCLUDED IN THIS PUBLICATION ARE BASED ON THE LATEST PRODUCT INFORMATION AVAILABLE AT THE TIME OF APPROVAL FOR PRINTING. HONDA MOTOR CO., LTD. RESERVES THE RIGHT TO MAKE CHANGES AT ANY TIME WITHOUT NOTICE AND WITHOUT INCURRING ANY OBLIGATION WHATSOEVER. NO PART OF THIS PUBLICATION MAY BE REPRODUCED WITHOUT WRITTEN PERMISSION. THIS MANUAL IS WRITTEN FOR PERSONS WHO HAVE ACQUIRED BASIC KNOWLEDGE OF MAINTENANCE ON HONDA MOTORCYCLES.

HONDA MOTOR CO., LTD.  
SERVICE PUBLICATIONS OFFICE

## Contents

	<b>General Information</b>	<b>1</b>
	<b>Frame/Body Panels/Exhaust System</b>	<b>2</b>
	<b>Maintenance</b>	<b>3</b>
<b>Engine and Drive Train</b>	<b>Lubrication System</b>	<b>4</b>
	<b>Fuel System</b>	<b>5</b>
	<b>Engine Removal/Installation</b>	<b>6</b>
	<b>Cylinder Head/Cylinder/Piston</b>	<b>7</b>
	<b>Kickstarter/Drive Pulley/Clutch/Driven Pulley</b>	<b>8</b>
	<b>Final Reduction</b>	<b>9</b>
	<b>Crankcase/Crankshaft</b>	<b>10</b>
<b>Chassis</b>	<b>Front Wheel/Suspension/Steering/Brake</b>	<b>11</b>
	<b>Rear Wheel/Suspension/Brake</b>	<b>12</b>
<b>Electrical</b>	<b>Charging System/Alternator</b>	<b>13</b>
	<b>Ignition System</b>	<b>14</b>
	<b>Electric Starter</b>	<b>15</b>
	<b>Lights/Meters/Switches</b>	<b>16</b>
	<b>Wiring Diagram</b>	<b>17</b>
	<b>Troubleshooting</b>	<b>18</b>

Index