



NOTE:

- The pedal height can be adjusted by turning the pedal joint on the master cylinder push rod.

Procedure	Q'ty	Remarks
<b>Removal Order</b>		Installation is in the reverse order of removal.
(1) Foot peg stay bolt	2	
(2) Heat guard	1	
(3) Push rod joint pin	1	Put through push rod joint and brake pedal from the out side, then secure with a new cotter pin.
(4) Brake pedal return spring	1	
(5) Rear brake light switch spring	1	Be careful not to strain too much during removal and installation.
(6) Snap ring	1	NOTE: • Install with the chamfered side facing brake pedal. • After installing, make sure it is fully seated in the groove.
(7) Thrust washer	1	
(8) Brake pedal	1	NOTE: • Do not lubricate to the pedal pivot.