

	1)	2)					
	600 miles 1,000 km	1,250 miles 2,000 km	4 months 2,500 miles 4,000 km	3,750 miles 6,000 km	5,000 miles 8,000 km	6,250 miles 10,000 km	12 months 7,500 miles 12,000 km
3)	R	R	R	R	R	R	R
4)	C				C		
5)			I		I		R
6)	I		I		I		I
7)	I		I		I		I
8)	I		I		I		I
9)			C		C		C
10)	I		I		I		I
11)			I		I		I
12)	I		I		I		I
13)							C
14)			I		I		I
15)	I		I		I		I
16)	I & L		I & L		I & L		I & L
17)			I		I		I
18)	I		I		I		I
19)	I		I		I		I
20)	I		I		I		I
21)	R				R		
22)	I		I		I		I
23)					I		
24)	I		I		I		I
25)	I		I		I		I
26)	I		I		I		I
27)			C		C		C

8. MAINTENANCE SCHEDULE

MAINTENANCE SCHEDULE

This maintenance schedule is based upon average riding conditions. Machines subjected to severe use, or ridden in unusually duty areas, require more frequent servicing.

- 1) INITIAL SERVICE PERIOD
- 2) REGULAR SERVICE PERIOD
Perform at every indicated month or mileage interval, whichever occurs first.
- 3) ENGINE OIL
- 4) OIL FILTER SCREEN
- 5) SPARK PLUG
- 6) CONTACT POINTS AND IGNITION TIMING
- 7) VALVE TAPPET CLEARANCE
- 8) CAM CHAIN TENSION
- 9) AIR FILTER ELEMENT
- 10) IDLE SPEED
- 11) CHOKE MECHANISM
- 12) CARBURETOR SYNCHRONIZATION
- 13) FUEL FILTER SCREEN
- 14) FUEL LINES
- 15) CLUTCH
- 16) DRIVE CHAIN
- 17) BRAKE SHOE/PADS
- 18) BRAKE CONTROL LINKAGE
- 19) WHEEL RIMS AND SPOKES
- 20) TIRES
- 21) FRONT FORK OIL
- 22) FRONT AND REAR SUSPENSION
- 23) STEERING HEAD BEARINGS
- 24) BATTERY
- 25) LIGHTING EQUIPMENT
- 26) ALL NUTS, BOLTS, AND OTHER FASTENERS
- 27) CRANKCASE BREATHER (SWISS TYPE)

I - Inspect, clean, adjust or replace if necessary

R - Replace

C - Clean

L - Lubricate