


Place the upper holder onto the lower holder.
Tighten the forward bolts first, then tighten the rear bolts.

TORQUE: 20–30 N·m
(2.0–3.0 kg-m, 14–22 ft-lb)

Install the bolt caps.



Install the right and left handlebars into the center handlebar.

Apply a thread locking agent to the set screw threads and install them.


Adjust both handlebars to the same position, using the set screws in the left and right handlebars and the holes in the center handlebar as a reference.

Apply grease to the handlebar pinch bolts and then tighten them to the specified torque.

TORQUE: 24–30 N·m
(2.4–3.0 kg-m, 17–22 ft-lb)

WARNING

Check the security of the handlebars by turning them all the way to the left and right and pushing and pulling on them with force.




MASTER CYLINDER

HOLDER

Install the front brake master cylinder and holder with holder "UP" mark facing up.

Align the end of the holder with the handlebar punch mark.

Tighten the upper bolt first, then the lower bolt.



PUNCH MARK "UP" MARK